



## 1182 Round Double Turn Pull Handle Lock Kit

### Tools Required

- Drill
- 25mm drill bit
- 20mm drill bit
- 14mm drill bit
- Pencil
- Chisel
- Ruler
- Square
- Hammer
- Pozi-drive bit
- 0# square-drive bit

### Parts included in 1182 Double Turn Lock Kit

- 1 x Euro 57 Mortice lock (including striker plate, cylinder screw and fixing screws)
- 1 x Round double turn set (including 8mm spindle shaft and fixing screws)
- 1 x 70mm Euro cylinder
- 1 x Round euro escutcheon set (including fixing screws and allen key)



SUPERIOR SERVICE, SOLUTIONS & STYLE IN ARCHITECTURAL HARDWARE

Windsor Brass Ltd | 42-48 Arena Avenue | PO Box 1595 | Invercargill 9840 | New Zealand

P: 0800 607 028 | F: +64 3 214 0070 | W: [www.windsorbrass.co.nz](http://www.windsorbrass.co.nz) | E: [sales@windsorbrass.co.nz](mailto:sales@windsorbrass.co.nz)

## 1182 Round Double Turn Pull Handle Lock Kit

### Fitting Instructions

1. Check Length and desired position of chosen pull handle and then mortice out door to fit lockcase.
2. Drill 25mm hole through door at 57mm back from door edge to fit spindle.
3. Mark two centre holes for the euro cylinder (20mm & 14mm) at 57mm back from door edge, drill out then chisel out the required amount to accept euro cylinder, do this on both sides of the door.
4. Check latch tongue is facing the correct way to locate on door frame. If necessary reverse tongue by inserting the blue 'golf tee' provided into the side of the lock case (refer to lock installation instructions), the latch tongue will protrude from the face of the lock, rotate 180° degrees then remove the tee and the latch tongue will drop back into position.
5. Fit lockcase to door with screws provided, then insert euro cylinder through door and into lockcase and fasten with the long cylinder screw provided. Fit lock face plate over face of lock and fasten with short machine screws provided.
6. Insert spindle into lockcase, ensure an even length is protruding out each side of door.
7. Fit turn plates to either side of the door over square spindle and fix with screws provided.
8. Fit euro escutcheon plates around euro cylinder and fix to door with screws provided.
9. Fit cover plates to both turns and escutcheons.
10. Crop out door frame in correct position to fit strike plate and dust box provided then insert dust box behind strike plate and fix to door frame with screws provided.
11. **ENJOY WINDSOR HARDWARE.**

**Note:** A strike packer will be required if fitting to doors with aluminium frames. Use code: **1159** for 8mm frames and code: **1155** for 10mm frames.

A rebate kit will be required for when fitted to rebated doors. Use code: **1105**

Extended striker plates also available to suit this lock kit. Code: **1164** can be cut to length up to 100mm.