



Aug 2007

## **INSTALLATION INSTRUCTIONS FOR LEVERS WITH WINDSOR SPLIT SPINDLE ADAPTORS**

- Use split spindle when using levers with Oval Vestible locks or similar.
- Important: Use 8mm spindle (**Code 1166**) with Legge 990  
Use 5/16in spindle (**Code 1167**) with Lockwood 3570 series  
For doors 52-68mm use **Code 1171**
- Ensure spindle is installed with the capscrew head on inside of an exterior door.
- Ensure the slots in the spindle are lined up with the grubscrew in the lever.
- Apply loctite to thread of capscrew, insert and tighten. After tightening completely, unwind  $\frac{1}{4}$  of a turn.
- Install Door Furniture and loctite lever grubscrews against spindle.
- Check levers are free to move independently.

**PLEASE NOTE QUATTRO DOOR FURNITURE IS ONLY COMPATIBLE  
WITH 38MM CENTRES AND 45° TRAVEL (OR LESS) LOCKS &  
LATCHES!**