



1184 Square Double Turn Pull Handle Lock Kit

Tools Required

- Drill
- 25mm drill bit
- 20mm drill bit
- 14mm drill bit
- Pencil
- Chisel
- Ruler
- Square
- Hammer
- Pozi-drive bit
- 0# square-drive bit

Parts included in 1184 Double Turn Lock Kit

- 1x Euro 85 Mortice lock (including striker plate, cylinder screw and fixing screws)
- 1x Square double turn set (including 8mm spindle shaft and fixing screws)
- 1x 70mm Euro cylinder
- 1x Square euro escutcheon set (including fixing screws and allen key)



SUPERIOR SERVICE, SOLUTIONS & STYLE IN ARCHITECTURAL HARDWARE

Windsor Brass Ltd | 42-48 Arena Avenue | PO Box 1595 | Invercargill 9840 | New Zealand

P: 0800 607 028 | F: +64 3 214 0070 | W: www.windsorbrass.co.nz | E: sales@windsorbrass.co.nz

1184 Square Double Turn Pull Handle Lock Kit

Fitting Instructions

1. Check Length and desired position of chosen pull handle and then mortice out door to fit lockcase.
2. Drill 25mm hole through door at 60mm back from door edge to fit spindle.
3. Mark two centre holes for the euro cylinder (20mm & 14mm) at 60mm back from door edge and drill out, then chisel out to accept euro cylinder, do this on both sides of the door.
4. Check latch tongue is facing the correct way to latch on door frame, reverse if necessary by lifting up the tab behind the latch tongue, push latch tongue into lockcase & rotate 180° degrees then release the latch tongue and ensure tab is returned to the downward position.
5. Fit lockcase to door with screws provided, then insert euro cylinder through door and into lockcase and fasten with cylinder screw provided.
6. Mark horizontal line around door with pencil in the centre of 25mm spindle hole, then insert spindle into lockcase, ensure an even length is protruding out each side of door.
7. Fit turn plates to either side of the door over square spindle and line up centre of plate with horizontal line marked on door fix with screws provided.
8. Fit euro escutcheon plates around euro cylinder and fix to door with screws provided.
9. Fit cover plates to both turns and escutcheons.
10. Crop out door frame in correct position to fit strike plate and dust box provided then insert dust box behind strike plate and fix to door frame with screws provided.

11. ENJOY WINDSOR HARDWARE.

Note: A strike packer will be required if fitting to doors with aluminium frames. Use code: **1186** for 8mm frames and code:**1185** for 10mm frames.

A rebate kit will be required for when fitted to rebated doors. Use code: **1146**

Extended striker plates also available to suit this lock kit. Code: **1234** (24mm tongue), **1187** cut to length up to 75mm.