



FUTURA 'Integrated Privacy' DOOR FURNITURE FITTING INSTRUCTIONS

Fitting Instructions for Codes: 9051, 9052, 9053, 9054, 9055, 9056

Through Screws included to suit door thicknesses 32-45mm.

These handles are designed to be fixed to door with through-fixing bolts and wood screws provided.

Latch

1. Measure the door thickness and mark the centre at desired height for latch.
2. Mark the face of door each side for drilling of spindle and screw holes.
3. Drill a 25mm (1") hole through door edge to a depth of at least 80mm.
Note: It is very important to drill this hole square to door.
4. Drill a 25mm (1") spindle hole through door face.
Note: The spindle hole will need to be centred at 60mm from the door edge (backset)
Note: For clean cut-outs, drill from both sides, meeting in the middle of door.
5. Drill 6.0mm holes for through bolts at 12o'clock and 6o'clock vertical positions for through fixing bolts and drill another 6.0mm hole at the horizontal position for the privacy pin as indicated in diagram above.
6. Remove any loose sawdust and insert latch. Scribe around face, remove, then chisel out recess to enable latch to sit flush with door edge.
7. Insert latch and fasten with screws supplied.
8. Gently close door against frame and mark latch position for fitting of strike plate. Router or chisel so plate fits flush, allowing for plastic recess box if required.

Note: Take extra care when working through step 2 of the instructions above when establishing the height & position of handles on the door, be sure to mark out both sides of the door the same to ensure the handles are even on both sides.

Note: For clean cut-outs drill from both sides, meeting in the middle of door. Drill 6.0mm (or ¼") holes for through door bolts.

Handles

1. With latch fitted to door, ensure all holes line up prior to fitting door handles.
2. Remove rose covers from levers.
3. Unthread screws from threaded sleeves. Insert threaded sleeve into oval holes in back of rose at the two vertical positions. Screw short bolts through from top of rose and tighten into threaded sleeve as indicated in above diagram.
4. Insert small spring into each lever and place each half of the spindle over the spring into the handle.
Note: These small springs are provided only to put pressure on each half of the spindle until the grubscrews are tightened. Each spindle has a hole in one end, this is for the spring to locate onto when inserted into the handle.
5. Insert handle from 'step 3' onto spindle, ensure the half spindle locates into latch.
6. Insert long thru-screws through other half of handle set and place on door, again ensuring the half spindle locates onto latch. Tighten screws securely.
7. In the screw hole directly below the lever arm, secure a wood screw then press on concealed fix covers, ensure the small hole in the cover plate lines up with the horizontal hole in the rose closest to the door edge.
8. Insert Privacy Stem through small hole in cover plate and thread through door into latch.
9. Tighten the grubscrew on inside of levers onto spindle each side of door.
Note: The grubscrews may need a re-tighten after a bedding-in period. We recommend medium strength thread-lock to be used, Windsor product code: 1276.
10. Test door and if necessary, adjust strike tongue to take up any rattle.